

Brick Edging Installation Checklist:

Preparing for Bricks:

- Clear the Area:
- Remove existing grass, weeds, and debris from the installation area.
Level the Soil:
- Use a leveling tool to create a straight and even surface for the bricks.
Mark Your Edging Line:
- Use string, stakes, or a garden hose to outline the desired path for the bricks.
Laying the Bricks:

Position the Bricks:

- Place the bricks along the marked edge of your garden bed or walkway, ensuring they are snug against each other.

Level the Bricks:

- Use a rubber mallet to gently tap the bricks into place and maintain a uniform height.
Creating Curved Borders:

Plan the Curve:

- Determine the desired curvature and position the bricks accordingly.
Use Stakes:
- Secure the curved bricks in place with stakes to maintain the shape.
Fill Gaps:
- Fill gaps between curved bricks with sand or crushed stones for stability and aesthetics.
Adding the Finishing Touches:

Fill the Gaps:

- Fill the gaps between bricks with soil, grass, or gravel to achieve a seamless appearance and anchor the bricks.

Use Landscape Adhesive:

- Consider landscape adhesive for added security and longevity, especially for high-traffic areas.